INSTALLATION GUIDE

TuneBasic™

1 Hardware Requirements: IBM-PC™ compatible computer with Windows 3.1.
CPU 25MHz 80386 with 4MB available RAM.
(Recommended:66MHz 80486 with 8MB available RAM)

2 Installation

1) Load Windows 3.1.
2) Open the Program Manager by double clicking the Program manager Icon.
3) Insert the TuneBasic™ Program Installation Disk (Disk 1 of 3) into the 3-1/2" floppy drive.
4) Click "File" in the Program Manager menu bar.
5) Click "Run..." in the file pull down menu.
6) Type "a:\setup" or "b:\setup" depending on the drive letter of your 3-1/2" floppy drive.
7) Click the "OK" button.

3 Getting User's Manual: You can get TuneBasic™ User's Manual for Microsoft Word™ or Adobe Acrobat® Reader.

1) Using Microsoft Word™
After install TuneBasic™, run "c:\TBASIC\TBDOC\TBDOC.EXE". TBDOC.EXE makes usre's manual file for Microsoft Word™. You can read user's manual file called "TBASICUG.DOC" with Microsoft Word™.

2)Using Adobe Acrobat® Reader
You can also read user's manual using Adobe Acrobat® Reader when you don't use Microsoft Word™. First,insert "Adobe Acrobat® Reader" disk and install it. After installation, read user's manual file called "TBMANU.PDF" in "TuneBasic User's Manual" disk using installed Adobe Acrobat® Reader.

4 Connecting

1) Slide switch to RS232C. The switch is located on DN1400F's rear panel.
2) Connect DN1400F and PC using 9P Dsub connecter.
Reccommended Cable: Belkin (EGA Monitor Ext Cable) F2N209 Series

5 Setting for one DN1400F

1) DN1400F
Changer's ID=0 (DN1400F's default setting)
Baudrate=19200

2) TuneBasic
Check "Denon DN-1400F" at "Configure Tune Basic" menu and select prefer serial port.
Set following items from "Changer Configuration Menu".
Numberof Changers=1
Left Tray Number=2
Changer Number=1
Right Tray Number=1

6 Setting for two DN1400Fs

1) DN1400Fs
Changer's ID=0 (DN1400F's default setting for first machine)
Changer's ID=1 (Setting for second machine)
Baudrate=19200 (Both machine)

2) TuneBasic
Check "Denon DN-1400F" at "Configure Tune Basic" menu and select prefer serial port.
Set following items from "Changer Configuration Menu".
Numberof Changers=2
For first machine:
Left Tray Number=2
Changer Number=1
Right Tray Number=1
For second machine:
Left Tray Number=4
Changer Number=2
Right Tray Number=3

For more details read user's manual.